

# Create a Meter Type

To create a new meter type, open the Meter Types Tab on the Settings Page of the Assets Module.

Settings

Asset Types Task Templates Meter Types Manufacturers Module Levels

Meter Types

Add Meter Type Search for Meter Type :  Search Clear

« Page 1 of 1 »

Meter Type ID	Status	Title	Description	Unit (plural)	Decimals	Input Option (Applies to update meter reading only)
1	...	Active	Blade Change	Changes	0	Actual

« Page 1 of 1 »

Select “Add Meter” opening the New Meter Type Modal.

This opens the New Meter Type modal.

New Meter Type

Title \*

Description

Unit (plural) \*

Decimals \*

Input Option (Applies to update meter reading only) \*

Actual

Save Cancel

Input the desired meter type title and description.

Include the units associated with this meter type.

Meter units should always be entered in plural form.

Input an integer to determine the number of place values after the decimals you would like recorder. Input 0 if you do not want to see any values after the decimal.

The Input Option dropdown menu has three options: Actual, Elapsed, Both. If you select both, a user can input the actual reading and elapsed value will be calculated. A user can also input the

elapsed reading and the actual will be calculated.

Select the “Save” button and the New Meter Type will be created and now shows on the Meters Tab on the Settings Page of the Assets Module.

---

Revision #2

Created 2025-12-07 20:23:14 UTC by Mitzi Orkus

Updated 2026-01-14 20:40:54 UTC by Mitzi Orkus