

View a Meter Type's Key Information

To view the key information about a specific meter type, go to the Meter Types Tab on the Settings Page of the Assets Module. Select the three-dot icon to the right of the meter type ID opening the Meter Type Context Menu.

Settings

Asset Types Task Templates Meter Types Manufacturers Module Levels

Meter Types

Add Meter Type Search for Meter Type: Search Clear

<< Page 1 of 1 >>

Meter Type ID	Status	Title	Description	Unit (plural)	Decimals	Input Option (Applies to update meter reading only)
1	...	Active	Time	Hours	1	Elapsed
2	...	Active	Miles	Miles	2	Actual
3	...	Active	Minutes	mins	1	Both
4	...	Active	Hours- Elapsed and Actual	Hours	0	Both

<< Page 1 of 1 >>

- View
- Edit
- Delete

Select "View" from the context menu opening the View Meter Type Modal which states all information regarding the specific meter type.

View Hours- Elapsed and Actual ✕

Meter Type ID: 4

Status: Active

Title: Hours- Elapsed and Actual

Description:

Unit (plural): Hours

Decimals: 0

Input Option (Applies to update meter reading only): Both

Close

The View Meter Type Modal is read-only.

Select the "Close" button and return to the Meter Types Tab on the Settings Page.

Revision #1

Created 2026-01-11 19:43:10 UTC by Mitzi Orkus

Updated 2026-01-11 19:48:10 UTC by Mitzi Orkus